DONCO kids


Fort Worth, Texas 76140


ASSEMBLY INSTRUCTIONS

1830 - TWIN SWEET DREAMS LOW LOFT




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present.
"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"







Tools Required



(Not included)




(Not included)

* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!
* Please assemble on a clean soft surface to avoid damage.

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY





Part List - 1830 - TWIN SWEET DREAMS LOW LOFT




Caution

Please be careful when assembling this product due the parts are extremely heavy. Also, please do not allow kids around when assembling this bed to avoid injuries.

Identifying the Hardware-Identify the hardware using the illustrations below.

A	 Ø 10x40	41
B	 Ø 8x25	38
C	 Ø 3,5X16	14
D	 Ø 4X30	31
E	 Ø 1/4X80 Cab 17	04
F	 Ø 7X110 Cab 17	12
G		04
H		02
I	 Ø 7X70 Cab 17	14
J	 Ø 4X30	26
K		07
L	 Ø 4X35	21
M	 Ø 7X60 Cab 17	18

01


A
Ø 10x40
41
B
Ø 8x25
38
01
03
05
x2
04
x4
06
x2
14
x3
10
x2
18
20
x2
21
19
x2
22
x4
24
26
28
x2
29


02


D	Ø 4X30	12

PLEASE ASSEMBLY THE
HEADBOARDS ON THE FLOOR


SCREW


D	L
Ø4X30	Ø4X35





RUSTIC
OUTSIDE



03
D
Ø 4X30
08
STEP 1
03
05
D
01
SCREW
D L
Ø4X30 Ø4X35
06
STEP 2


04
07
03
01

05


F	Ø 7X110 Cab 17	08
H		01

PLEASE ASSEMBLY THE HEADBOARDS ON THE FLOOR




06 SHELVES


L	Ø 4X35	04



SCREW




07



H		01
M	Ø 7X60 Cab 17	06

08 LADDER



H		01
M	Ø 7X60 Cab 17	06


10

09

F	Ø 7X110 Cab 17	04
H		01


PLEASE ASSEMBLY THE HEADBOARDS ON THE FLOOR

RUSTIC OUTSIDE




10


H		01
L	Ø 4X35	01
M	Ø 7X60 Cab 17	06



SCREW



11




E	Ø 1/4X80 Cab 17	04
G		04
H		01
I	Ø 7X70 Cab 17	04

INSERT AND ATTACH BOLTS E+G & I,
BUT DO NOT TIGHTEN UNTIL STEP #14


12

H		01
I	Ø 7X70 Cab 17	02




HOLES INSIDE


13

H		01
I	 Ø 7X70 Cab 17	08


AFTER INSERTING PARTS #22, AT THIS TIME, PLEASE TIGHTEN ALL BOLTS.


14

L	 Ø 4X35	13



SCREW






15

PLEASE ASSEMBLY THE
HEADBOARDS ON THE FLOOR

L	Ø 4X35	02

SCREW



RUSTIC
OUTSIDE


16

D	Ø 4X30	11

SCREW




17




L	Ø 4X35	01

18








C	Ø 3,5X16	14
K		07


Part List - 1830 - CHEST 3 DRAWERS LOW LOFT



Identifying the Hardware-Identify the hardware using the illustrations below.

H		01	Q		03
L	 Ø 4X35	34	R		03
M	 Ø 7X60 Cab 17	04	S		03
N	 Ø 6X10	24	T		23
O	 Ø 4X22	12	U		03
P		03	V	 Ø 8X30	38


19



SET OF METAL SLIDES FOR THE DRAWERS

The metal glides hardwares are all in one packed. Please separate the left and right pieces like a pair.


- The glides # P # Q are used on chest panel side and has a left and right pieces.
- The glides # R # S are used on drawers side, also has a left and right pieces.




(Q)	(P)	(S)	(R)
(x3)	(x3)	(x3)	(x3)
Please fix on panel side #32	Please fix on panel side #31	Please fix on drawer side #39	Please fix on drawer side #40

20


N	Ø 6x10	12
P		03
Q		03






The wheel to the front !


The wheel to the front !




21



22




23



H		01
M	Ø 7X60 Cab 17	04


24



T		23
U		03


25

L	Ø 4X35	24




26

O	Ø 4X22	12




27




N	Ø 6x10	12
R		03
S		03

28




29



30

ATTENTION
THERE MUST BE A LEAST 5" INCHES
FROM TOP SURFACE OF MATTRESS TO
TOP EDGE OR GUARDRAILS.
"MATTRESS 9" HIGH LIMITED"

J	Ø 4X30	26



"INSTALL SLAT KIT WITH SPACER
TAPE ON TOP (FACING UP)"

