



FLEXSTEEL®
HOME

Battery Pack 2

The battery pack 2 is a reliable, rechargeable battery for your Flexsteel power reclining furniture.

- No need to place your furniture near an outlet
- One charge will last up to 150 cycles
- Works even during a power outage

NOTE: This battery pack should not be used on lift reclining furniture. It is also not recommended for use on 601M or 604P styles with cup holder controls as the touch sensors will drain the battery and greatly reduce the number of cycles per charge.

The battery pack carries a one-year limited warranty.

Charging Information

- Red LED: A FLASHING red LED indicates the battery pack is being charged.
- Green LED: A SOLID green LED means the battery pack is fully charged (after eight hours). The green light goes out when the battery pack is plugged into the furniture or is in standby mode.
- An audible warning (beeping) signal warns the user that the charge is VERY LOW and the battery pack must be charged.

Technical Information

- The battery pack consists of 24V/2.3Ah lithium ion rechargeable batteries.
- The battery pack can provide up to 150 complete cycles (from upright to reclined and back to upright) at a weight of 175 pounds on one charge. The quantity of cycles will decrease or increase depending on the weight of the user(s). Some furniture features optional USB ports. Using the USB ports will consume power from the battery pack and will decrease the quantity of cycles for that charge.



SKU: BATT-PK2



FLEXSTEEL®
HOME